

MIDIPLUS

MIDI 16X16 Owner's Manual



Contents

Preface.....	3
What's in the Box?	3
MIDI16X16 Overview :	3
Front panel view :	4
Back panel view :	4

Preface

Thank you for purchasing the MIDIPLUS MIDI16x16 USB MIDI Interface. You can connect up to 16 MIDI keyboards or MIDI hardware to your computer system. You have up to 512 MIDI channels you can easy and clearly arranged work with.

What's in the Box?

The following items should be in your package.


- One MIDI 16x16.
- Owner's Manual.
- One standard USB Cable.

MIDI16X16 Overview :

Technical specs of the MIDI16x16:

- Easy to connect to your Computer with USB 1, 2 or 3.
- Works driverless class compliant with Windows XP SP3, Vista 32/64 Bit, Windows 7 32/64 Bit, Windows 8 32/64 Bit, Windows 10 32/64 bit and Mac OS X.
- 32 LEDs for MIDI Input and Output activity.
- USB Powered, no additional power necessary.

Front panel view :



The cabinet of the MIDI16x16 is clearly marked. On the front side you find the MIDI IN/OUT signal LED 1 to 16, they show you each Input and output MIDI activity. Please note that always MIDI In ports must be connected to MIDI Out ports. Please do NOT use an USB Hub.

Back panel view :



On the back side you find the MIDI IN/OUT ports 1 to 16. At these ports you can connect your MIDI hardware with standard MIDI cables. You also can find the USB port. Please connect this USB port with the USB cable to a free USB port on your computer. Please do NOT use an USB Hub. Because the MIDI16x16 is "class compliant", you do not need to install a driver. If the MIDI 16x16 is not recognized correct, please update your mainboards or notebooks USB chipset drivers. Also please update for Intel system the Intel.inf drivers, for AMD systems the AMD chipset drivers. The MIDI16x16 is full USB powered; you do not need additional power or batteries.

Have much fun with this product!

*Design and specifications subject to change without notice

*No liability for printing mistakes